

GGT-01 Removal



1) Remove pistol magazine, and make sure no ammunition is chambered in the weapon. **Physically and visually confirm this fact.**

2) Place bottom back edge of magazine under “lip” of GGT-01 and apply pressure away from weapon until GGT-01 releases from grip (see photo)



3) **NEVER** use any other item to remove the GGT-01. Ballpoint pens, screwdrivers, keys, etc. will damage the plug locking tab and eliminate its ability to be retained in the weapon grip.